_____

How to install the SW (X-CUBE-MEMS2) for using the X-NUCLEO-IKS01A1 and NUCLEO-F401RE

1) You must have:
- **X-NUCLEO-IKS01A1** - MEMS environmental sensor expansion board for STM32 Nucleo
- **X-CUBE-MEMS2** - STM32Cube expansion software for X-NUCLEO-IKS01A1
- **CUBE-F401RE** - STM32 Nucleo development board for STM32 F4 series - with STM32F401RE MCU, supports Arduino

2) **Plug** the **X-NUCLEO-IKS01A1** on the **NUCLEO-F401RE**

3) **Connect the NUCLEO-F401RE** (with plug in the X-NUCLEO-IKS01A1) **to the PC**

4) Now **unzip** the **X-CUBE-MEMS2** and **install** the:
  osxMotionFX_Setup_v1.0.0.exe
  (v1.0.0 is the release of my installation).
  ATTENTION: for do this installation are request the administrator permission.
  At the end of the installation, run **Open.MEMS - MotionFX for STM32** (see below).

_____

From the window that appears select **1** and after **2**, see below.

Now press: **Send license request email..** (see below).